


87-G42-3699-08 KEYSWITCH PANEL (GX-4200)



KEYSWITCH PANEL

87-G42-3699-08

PART #	DESCRIPTION	QTY
99-280-7018-06	SPLIT WASHER, #8	2
99-G20-7511-01	LOCK WASHER #8 EXT. TOOTH	8
99-G20-7513-11	NUT, NYLOC 8-32	6
99-G20-8534-00	CABLE, CHOKE	1
99-G20-8543-05	INSTRUCTIONS, STARTING	1
99-G20-9505-00	VOLTMETER	1
99-G20-9506-00	LIGHT KIT	1
99-G20-9507-00	HOUR METER	1
99-G20-9520-00	DISCONNECT, 1/4 MALE	8
99-G20-9529-00	COUNTER, FEET OR METER	1
99-G20-9532-00	FUSE HOLDER, GS1000 & G2000	1
99-G30-3531-00	PANEL, KEY SWITCH	1
99-G30-8527-03	SWITCH, KEY	1
99-G30-9520-00	COUNTER, FT/MIN	1
99-G30-9533-00	FUSE 25 AMP	1