

GUIDE ARM 87-G42-3699-11

PART #	DESCRIPTION	QTY
99-280-1011-00	WHEEL, YELLOW	1
99-280-7006-04	1/4-20 X 3/4 SHCS SST	3
99-280-7006-05	1/4-20 X 1 SHCS SST	1
99-280-7007-02	1/4-20 X 3/4 FHS	4
99-280-7012-02	10-24 NYLOC NUT CAD PLATED	4
99-280-7017-02	1/4-20 NYLOC NUT	4
99-280-7018-07	LOCK WASHER 1/4 SPLIT	3
99-280-7020-03	FLAT WASHER, 1/4 SST	7
99-G20-1578-00	PLATE, GUIDE ARM MOUNT	1
99-G20-1579-00	PLATE, GUIDE ARM MOUNT	1
99-G20-1606-03	BUSHING, GUIDE ARM	1
99-G20-1608-00	BAR, ACTUATOR SUPPORT	1
99-G20-1614-00	SPRING, GUIDE ARM BLOCK	1
99-G20-1615-00	BLOCK, GUIDE ARM RETURN	1
99-G20-1616-00	BLOCK, GUIDE ARM RETURN (SMALL)	1
99-G20-1617-01	BUSHING, SPLIT GUIDE ARM	1
99-G20-1617-02	BUSHING, GUIDE ARM	1
99-G20-1623-00	BUSHING, GUIDE ARM	1
99-G20-1629-00	SHAFT COLLAR 3/4"	2
99-G20-1642-00	PLATE, HOOD SUPPORT	1
99-G20-1644-00	BUSHING, HOOD SUPPORT DELRIN	1
99-G20-3642-01	SPACER, HOOD STOP	1
99-G20-7020-03	FLAT WASHER 1/4 DELRIN	10
99-G20-7503-01	1/4 X 5/8 SHSB BLACK STEEL	2
99-G20-7503-02	1/4 X 3/4 SHSB BLACK STEEL	1
99-G20-7505-01	1/4-20 X 1 H.H. SST.	1
99-G20-7506-01	1/4-20 X 1 1/2 SHCS SST	1
99-G20-7506-02	1/4-20 X 2 SHCS SST	1
99-G20-7516-01	1/4-20 X 3/8 SET SCREW CUP.	2
99-G20-8500-04	BEARING, GUIDE ARM SHAFT	3
99-G20-9500-05	ACTUATOR, GUIDE ARM	1
99-G30-3576-00	TUBE, GUIDE	1
99-G30-3577-00	SHAFT, GUIDE ARM	1
99-G30-3602-01	EXTENSION, THROTTLE	1
99-G30-3641-00	BAR, GUIDE ARM EXTENSION	1
99-G30-3725-00	BLOCK, GUIDE TUBE MOUNT	1
99-G30-7503-08	SHSB, 1/4 X 7/8	1
99-G30-7507-01	FHS 1/4-20 X 1 1/4	4
99-G30-8505-04	GUIDE SPRING	1
99-G30-8508-03	BUMBER, GUIDE (RUBBER)	1